



## Setting up the tent:




Take the tent out of the bag, remove the strap and release the tent away from you with a spin to self erect. CAUTION: STEP BACK TO AVOID CONTACT WITH THE TENT AS IT ERECTS.


## Taking down the tent




To dismantle, remove stakes. Unzip door.



Form a "taco" shape by gathering top and base edges together at center.



Lift the tent up, with one hand grasp the top and base at the center, with the other hand push the edge labeled H down toward the ground.




Tuck back the edge labeled H down and inward until it forms ring shapes on ground.



Slide rings over the top of each other and adjust rings to lie on top of one another.



When all rings are together, secure tent between legs and slide strap over rings to hold them together.



Slide tent into bag. Then place accessories into bag to store.